

072450 Yamaha MT-10 Hugger Fitting Instructions

Kit Includes:

1X C072450 Moulding
2X SLOA001 M6 X 25_{mm} Bolts

2X SLOA001 M6 Countersunk Washers

2X SLOA001 M6 Spacers

- The Pyramid Hugger fits into the same three mounting points as the OEM Hugger.
- The fittings provided mount onto the forward two mounting points. See Fig 2 for the fitting sequence.
- The OEM clip removed from the side mounting point can be re-attached to the Pyramid Hugger once the forward mounting points are fitted.

Note: We advise that all fixings are checked periodically.

